

# ATARI®

## CONTROLLERS



**The ATARI® Controllers** can be used with the ATARI 400™ or the ATARI 800™ Personal Computer System. They can be plugged into any one of the four controller jacks on the front of the computer console. You can write your own programs which use the Joystick (CX40), Paddle (CX30) and Keyboard Controllers (CX50), and the ATARI Light Pen (CX70).



# CONTROLLERS

Press the ATARI Light Pen against your television screen and your computer records the position on the screen. Write your own programs. You can paint multi-colored scenes, pick items from a menu, play games or have your computer do geometric calculations for you. Your ATARI Light Pen comes with complete instructions and a demonstration cassette.

Many ATARI programs use the Joystick (CX40) and Paddle (CX30) Controllers. You can also write your own programs which use them or the Keyboard (CX50) Controllers.

## LIGHT PEN FEATURES & SPECIFICATIONS

- Use with the ATARI 400™ or ATARI 800™ Personal Computer System.
- Plugs into controller jack.
- Use in all graphics modes.
- Can be used with BASIC, PILOT, assembly language and other ATARI programming languages.
- Paint in up to 5 colors.
- Lightweight.
- Includes demonstration cassette.
- Method of operation: The Light Pen reads the coordinates of the TV electron beam as it passes the Light Pen.
- Resolution: Equivalent to the cursor on the screen (one letter position).
- Updating: Every frame—60 times a second.
- Light sensitivity: Operates under normal viewing conditions with all home televisions and monitors.
- Switch: Includes tip switch to signal computer when pen is pressed to screen.
- Dimensions: 7"x7/8", 3 oz., 4-ft. cord.

## ATARI Personal Computer System programs which use CONTROLLERS

### Joystick Controller:

Basketball CXL4004 (1-4)  
Computer Chess CXL4009 (1)  
Graph It™ CX4109 (one optional)  
Hangman CX4108 (one optional)  
Space Invaders\* (1-2)  
Star Raiders™ (1)  
Statistics I CX4103 (one optional)  
3-D Tic-Tac-Toe (1-2)  
Video Easel™ (1-4)


### Paddle Controllers:

Super Breakout® CXL4006 (1-4)

Weight: Joystick Controller: 7 oz.  
Paddle Controller (pair): 9 oz.

Warranty: 90 days parts and labor.

Service: Available at ATARI authorized service locations.



\*Trademark of Taito America Corporation.

All product illustrations and specifications are based on authorized information. Although all descriptions are believed correct at publication approval, accuracy cannot be guaranteed. Some of the equipment shown on the product illustrations is optional at extra cost. ATARI Personal Computer Division reserves the right to make changes from time to time, without notice or obligation, in prices, specifications, colors and materials, and to change or discontinue models.

1265 Borregas Ave. Dept. C, Sunnyvale, California 94086  
Call toll-free 800-538-8547 (In Calif. 800-672-1404) for the name of your nearest ATARI retailer.

PERSONAL  
COMPUTER  
SYSTEMS



 A Warner Communications Company