Adapter for 2732 in a TMS2532 Socket

Top Socket 2732

Bottom Socket TMS2532

Top Socket Pin 21 (A11) connected to Bottom Socket Pin 18 (A11)

Top Socket Pin 20 (Vpp) connected to Bottom Socket Pin 21 (Vpp)

Top Socket Pin 18 (-CE) connected to Bottom Socket Pin 20 (-CE)